

DVD / MP3 / CD PLAYER AM / FM STEREO

FREQUENCY RANGE :
FM 87.5 ~ 108.0 MHz
AM 522 ~ 1710 KHz

Wiring Diagram

CAUTION : +12V, DC NEGATIVE GROUND

