

Optional accessories

12/24V Hardwire lead

Extension GPS antenna

Carry case

To order call 01928 579 579



MY-TRAK

WPT250

Service under warranty

My Trak WPT250 comes with a standard one year manufacturer's warranty.

Please note: Before returning this product please visit 'Troubleshooting' at

www.snooperneo.co.uk

If your unit requires service under warranty return it, via Special Delivery or equivalent insured courier service in suitable packaging to:


**The Returns Department, Performance Products Limited
Cleaver House, Sarus Court, Manor Park, Cheshire WA7 1UL**

Enclose the following information:

- Your name, address and a full description of the problem.
- A telephone number where you can be reached during business hours.
- Your units' serial number.

Customer service

Tel: 01928 579 579 Email: technical@snooper.eu




Quick Start Guide



My-Trak WPT250 – Quick Start Guide

Getting to know your My Trak WPT250



2. Battery light indicator

Red when battery low and requires charging. Orange when charging. Green when fully charged.

3. GPS indicator

Red flashing LED – No GPS connection

Green flashing LED – GPS connection successful

4. GSM indicator

Green flashing LED – GPRS connection successful.

No LED – No GPRS connection

5. Power button

Press and hold for 5 seconds to power on. 3 Green LEDs will flash for a few seconds as WPT250 boots up. Press and hold for 5 seconds to power off.

Please note it may take a few minutes for WPT250 to connect to GPS and GPRS after you have powered it on.



1. USB charger socket

Charge your WPT250 using the AC charger provided. It will take approximately 3 hours to fully charge.

Using your My Trak WPT250

My Trak WPT250 operates with the My Trak LIVE web tracking service. To register and set up your WPT250 visit www.my-trak.co.uk where you will also find full information of the many different functions of your unit plus instructions on how to get the most out of your My Trak WPT250.