

MR632UAB
USER MANUAL
BLUETOOTH® | 200 WATTS
FULLY MARINIZED MP3-COMPATIBLE
DIGITAL MEDIA AM/FM RECEIVER
WITH DETACHABLE FRONT PANEL
FEATURING MULTICOLOR ILLUMINATION



V-9G

Installation

Installation Procedures


First complete the electrical connections and then check for correctness of connection.

Installation Opening

This unit can be installed in any dashboard which has an opening as shown below.





Insert the mounting sleeve into the dashboard. Then bend the tabs on the mounting sleeve with a screwdriver to achieve fastening of the mounting sleeve.
Make sure that lock lever is flush with the mounting sleeve(not projecting outward).



Installation


Connect all wiring harness and slide the head unit into the mounting sleeve until it clicks into place.

Wiring Connections



- +12V DC Negative Ground.
- Only support speakers of 4 ohms or above.
- The maximum current of the Amp remote trigger is 200mA.
- The equipment shall be protected by the circuit with max. 10 Amperes of the front end of DC source.

Overview of the Components



REMOVE PANEL



1. (power on/off) / SRC (source) button
2. (tune/seek down, previous track, fast reverse) button
3. VOL (volume) knob, (Push-To-Talk) button, SEL (select/menu) button
4. (tuner seek up, next track, fast forward) button
5. RDM (random), Preset station 4 button
6. Hands-free Microphone
7. -10 (previous 10 tracks), previous folder, Preset station 5 button
8. LCD Display
9. USB Port
10. Release button
11. AUX IN (aux audio input) jack
12. +10 (next 10 tracks), next folder, Preset station 6 button
13. CLK (clock setting), (end call) button
14. BND (BAND)/AMS (auto store station, auto music search) and (answer call) button
15. MUTE button
16. RPT (repeat), Preset station 3 button
17. INT (intro), Preset station 2 button
18. (pause/play), Preset station 1 button
19. Reset button

General Operation

Turn Unit on/off, Change the Source

- Press the button to turn on the unit. Press and hold the button to turn off the unit.
- Press the button to select the different modes: Radio, USB (with USB device inserted), BT (Bluetooth) and AUX-IN (aux audio input) modes.

Adjust the volume (VOL)

Rotate the VOL knob to increase or decrease the volume level.

General Operation

Push-To-Talk

Press the icon button (VOL knob) to access to smartphone voice assistant capability via Bluetooth.

Adjust Menu Options (SEL)

• Press and hold the SEL button (volume knob) to enter into setting menu, then press the SEL button (volume knob) repeatedly to select setting items:

- BASS/TREBLE: 7, 6, 5, 4, 3, 2, 1, 0, +1, ~, +6, +7

Note: BASS and TREBLE settings are only enabled when EQ setting is turned OFF.

- BALANCE: L7, L6, ~, L1, 0, R1, ~, R6, R7

- FADER: R7, R6, ~, R1, 0, F1, ~, F6, F7

- EQ (Equalizer) Setting: OFF, FLAT, CLASS, POP, ROCK, JAZZ

- Loudness: LOUD ON/OFF

- DX/LOCAL: Enables or disables the local broadcast mode (LOCAL).

- Stereo/Mono: Switches between MONO and STEREO reception mode for radio frequencies.

- CLOCK 12/24: Select between 12 hours and 24 hours display.

- AREA US/EU: This car radio is equipped the USA / Europe frequency.

Rotate the volume knob to switch between USA and Europe frequency.

The system will change the frequency setting in about 3 seconds.

- 7 color-changing illumination in buttons:

The illumination color can be preset Auto/color automatically change one by one) Blue, Red, Cyan, Green, Purple, Yellow, White.

• Rotate the VOL knob to change values.

Mute On/Off

Briefly press the MUTE button to toggle mute on or off.

Clock Display/Settings

Press the CLK button to display clock time.

Press and hold the CLK button, the hours digits start flashing on the display.

Set hours by rotating the volume knob. Short press the CLK button, the

minute digits start flashing. Set minutes by rotating the volume knob.

USB Port

Connect to a USB device for audio play, or charging of a mobile phone.

Hands-free Microphone

To receive your voice when you calling by using this bluetooth handsfree system.

Aux Audio Input Jack

Connect to the headphone jack on an external device (e.g. a mobile phone or MP3 player) for audio play.

General Operation

Release the detachable front panel

Press the release button to detach the front panel.

Reset

Push the RESET button with a thin object with a pointed end to reset the unit. This function may be used when the LCD does not display normally or sound is distorted, or when any of controls are disabled.

Radio Operation

Switch Between USA area and Europe area Frequency

In radio mode, press and hold the SEL button (volume knob) to enter into setting menu, then press the SEL button (volume knob) repeatedly to access the state of the USA and Europe frequency, then rotate the volume knob to switch between USA and Europe frequency. The system will change the frequency setting in about 3 seconds.

Change Bands

In radio mode, shortly press the BND button to switch between the FM1 (F1), FM2(F2), FM3(F3) and AM1(A1), AM2(A2) bands.

To Store / Recall Preset Stations

The radio can be stored 6 preset stations for each band (FM1, FM2, FM3, AM1 and AM2) for a total of 30 preset stations.

To memorize a station:

• Press and hold the desired preset buttons (1-6) to save a radio station.

To recall a preset station:

• Briefly press the respective station button (1-6) to recall the corresponding preset station.

Manual Tuning

In the radio mode:

Press and hold the or button to enter the manual tuning mode. In manual tuning mode, briefly press the or button to search the next or previous frequency step by step.

Seek Tuning

In radio mode, press the or button, the automatic search will start, it will search upward or downward for the strong signal radio station within the current band. The auto searching will stop until find a station.

Automatic Store Station / preset station scan

Press and hold the AMS button to store 18 FM stations and 12 AM stations automatically.

USB Operation

Play MP3/WMA music on a USB.

Insert a USB flash drive with MP3/WMA musics into the USB port. Play will start automatically.

Note: the USB port also supports charging mobile phone, the maximum charging ability is 5V/1A.

Select Next Track or Previous Track

In the USB mode, briefly press the **▶▶** or **◀◀** button to play the the next or previous track.

Fast Forward/Reverse

Press and hold the **▶▶▶** or **◀◀◀** button to fast forward or reverse a track.

Play / Pause

Press the **▶||** button to interrupt the playback of a music (pause function). Press this button again to continue the playback.

Introduction Scan

Press the **INT** button to play the first 10 seconds of each track. Press again to stop the introduction scan, and play the current track.

Repeating the track

Press the **RPT** button to toggle between RPT ONE (Continuously repeat current track) and RPT FLR (Continuously repeat all tracks in current folder), RPT ALL (Play all track).

Playing all tracks in random

Press **RDM** once, play all tracks randomly. Press **RDM** once again, exit from random playback.

Track/Folder Navigation

- Press the **-10/+10** buttons to jump 10 tracks backward or forward. It is required that over 10 tracks be available on the storage medium.
- Press and hold the **-10/+10** button to select the previous or the next folder. (if there are folders on the storage medium.)

Select the track or file for playback in MP3 format

- Press and hold the **AMS** button to enter track search mode.
- Rotate the volume knob to select the number of your favorite track with high speed.
- When the desired track number appears, confirm your selection by pressing the volume knob.

Aux Audio Operation

It is possible to listen to other playback devices such as MP3 players, CD players etc. through your car loudspeakers.

- Using a 3.5 mm audio cable (not included), connect a playback device with a 3.5 mm headphone jack to the 3.5 mm AUX input jack on the unit.
- Press the **SRC** button repeatedly until "AUX IN" appears in the display.
- Now you can listen to the external device via the loudspeakers. You can adjust the volume of the external device to a comfortable level with the volume control of the external device.

Bluetooth Operation

Pair and Connect

Pair the mobile phone with the device before using it.

- In any mode, prior to pairing and connecting, the BT logo is flashing in the LCD indicating that no device is connected. To begin pairing, enable BT mode on your mobile phone.
- When the phone finds the car audio system, the "BOSS AUDIO MR632UAB" name will be displayed.
- Choose the "BOSS AUDIO MR632UAB" from the device list to pair and connect with the car audio system. Upon confirming, the BT logo will stop flashing.
- When pairing is complete, the mobile phone audio will automatically transfer to the car audio system whenever a call is made or received, or when the mobile phone plays music.

Make a Call

To make a call, dial the call directly from the paired mobile phone.

Answer a Call

When the mobile phone is called, the incoming telephone number displays on the LCD display. Press the **☎** button to receive the incoming call.

Reject or End a Call

To reject or end the call, press the **☎** button.

Bluetooth Operation

Redial Last Dialed Number

Press and hold the **☎** button to redial the last dialed phone number.

Switch Audio Between Car Audio and mobile Phone

During a call, press the volume knob to switch the audio source from the car audio system back to your mobile phone.

Audio Streaming (A2DP)

The unit supports A2DP (advanced audio distribution profile) wireless streaming audio from your Bluetooth mobile device directly to your head unit. You can also control your music from the front panel of the head unit using AVRCP (audio video remote control profile).

- After pairing, connecting and enabling streaming audio from a compatible mobile device, press the **SRC** button to enter BT mode and the "BT AUDIO" will be shown on the LCD display.
- When a mobile device is paired, music played through that device will automatically be heard through the car audio system.
- Press the **▶▶** or **◀◀** button to play the next or previous on the mobile phone.
- Press the **▶||** button to pause or resume music playback.

Push-To-Talk

This Push-To-Talk feature allows direct access to Android and IOS smartphones voice assistant capability when you establish the Bluetooth connection between your smartphone and this unit. When Bluetooth connection is made, press the volume knob (**Ⓜ**) to activate voice assistant then speak your command.

Note:

- Before using the Push-To-Talk, enable the mobile data on your smartphone for online services (e.g. navigation and online music).
- To use the navigation feature, switch to the BT Audio source to hear voice commands over your car speakers.

Troubleshooting

If you suspect something is wrong, immediately switch power off. Do not use the unit in abnormal condition, for example without sound, or with smoke or foul smell. Otherwise this can cause fire or electric shock. Immediately stop using it and call the store where you purchased it. Never try to repair the unit by yourself because it is dangerous to do so.

■ General

- 1) **Car's engine switch is not on.**
Turn you car's key to ACC or ON.
- 2) **Cable is not correctly connected.**
Check the connection.
- 3) **Fuse is burnt.**
Replace fuse.
- 4) **Volume is in mute or minimum.**
Check volume or mute on/off, adjust volume to a desired level.
- 5) **The operation keys do not work.**
The built-in micro-computer is not operating properly due to noise. Press the RESET button to restore the program to zero.

■ Radio

- 1) **Much noise in broadcasts.**
Station or signal is too weak. Select other stations of stronger signal level.
- 2) **The antenna cable is not connected.**
Insert the antenna cable firmly into the antenna socket of this car radio.
- 3) **Pre-set station is reset.**
Battery cable is not correctly connected. Connect the battery cable to the terminal that is always live.

■ USB

- USB is connecting but no sound**
- a) USB connection is not good. Take it out and insert again.
 - b) USB is damaged or no music file inside.
Change to another USB, or record music inside it.

Specifications

General

Power supply Requirement : DC 12V
Maximum power output : 50W X 4CH
Speaker impedance : 4 - 8 Ohm
Standby current : 40mA (with ACC on)
Unit Dimensions(WxHxD) : 7.0 X 2.0 X 2.76 inches
Weight : 0.99 lbs
Fuse : 10 A

RADIO

FM
Frequency Range:.. 87.5 MHz - 107.9 MHz (USA)
87.5 MHz - 108.0 MHz (EUROPE)
Channel step: 200 KHz (USA)
50 KHz (EUROPE)

AM

Frequency Range: 530 KHz - 1710 KHz (USA)
522-1620 KHz (EUROPE)
Channel step: 10 KHz (USA)
9 KHz (EUROPE)

USB

Usable Audio Formats: MP3/WMA
USB Port Type: 2.0
USB Charging: 5V/1A

Audio

Pre-amp Output: Front and Rear
RCA Output Voltage: 1 V
Frequency Response: 20 Hz - 20KHz
S/N Ratio: 60dB

BT

BT Profile supports: Headset, Handsfree and A2DP & AVRCP
Range of frequency: 2.4GHz

BOSS
AUDIO SYSTEMS



BOSS Audio Systems
3451 Lunar Court • Oxnard, CA 93030
www.bosssaudio.com
805-751-4853 Customer Service
Tech Support: www.bosssaudio.com/support



0724

iPhone® is a trademark of Apple, Inc. registered in the U.S. and other countries. BOSS Audio Systems is not affiliated with Apple, Inc. The Bluetooth® word mark and logo are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by BOSS Audio Systems is under license. Other trademarks and trade names are those of their respective owners.